






LIDO K 3 D



WSKAZÓWKA DOTYCZĄCA PIELĘGNACJI !PROSZE CZYSZCZYĆ TYLKO SUCHĄ LUB LEKKO WILGOTNĄ SZMATKĄ DO KURZENIA UŻYWAĆ ŻADNYCH ŚRODKÓW SZORSTKICH !



8.0x35 D	4.0x25 G	 X	 A	 B	3.5x16 H	 S1	 F	 I	 S3	 L
20	6	16	16	16	12	15	3	8	8	6
 Z	 S4	 S5	3.5x16 V	 Q	 S	 U	 X1			
6	4	8	4	4	1	1	1			

No.	Stc.	L	W	T
1	1	1200	400	16
2	1	1168	380	16
3	1	864	400	16
4	1	864	400	16
5	1	788	380	16
6	1	788	380	16
7	2	434	360	16
8	1	360	264	5
9	1	1168	60	16
10	2	870	448	16
11	1	200	295	16
12	1	200	295	16
13	2	480	262	4
14	2	812	448	3
15	1	812	283	3

