






























LAUREN SB











- (D)** Montageanleitung
- (NL)** Handleiding voor de montage
- (TR)** Montaj talimatı
- (FR)** Instructions de montage
- (CZ)** Montážní návod
- (HU)** Összeszerelési útmutató
- (GB)** Assembly instructions
- (PL)** Instrukcja montażu
- (RU)** Инструкция по монтажу
- (IT)** Istruzioni di montaggio
- (RO)** Instrucțiuni de asamblare
- (SK)** Montážny návod













		39	 X 5	35	 X 5
1	 X 20	29	 X 2	30	 X 1
2	 X 16			22	 X 20
3	 X 6	13	 X 8	25	 X 6
4	 X 12	9	 X 10	23	 X 6
5	 X 4	10	 X 5	61	 X 12
6	 X 22	26	 X 1	60	 X 1 670 mm
12	 X 80	24	 X 6		


















$x1 = x2$







ACHTUNG / ATTENTION
Auflage / Size
SA 2 443 MM X 85 MM
SA 5 455 MM X 378 MM








ACHTUNG / ATTENTION
Auflage / Size
SC 2 443 MM X 85 MM
SC 5 455 MM X 378 MM













ACHTUNG / ATTENTION
Auflage / Size
SB 2 452 MM X 85 MM
SB 5 464 MM X 378 MM









ACHTUNG!
SCHUTZFOLIE AUF
DIE FRONTEN. BITTE
VORSICHTIG ABZIEHEN
UND 14 TAGE
DIE FRONTEN
NICHT PUTZEN, DA DIE
OBERFLACHE ABHARTEN
MUSS. SONST WIRD
DIE FRONT ZERKRATZT!